

## ASSEMBLING INSTRUCTION

### WINDSHIELD

HCF5300-16

[WWW.BARRACUDAMOTO.COM](http://WWW.BARRACUDAMOTO.COM)

## LEGEND

- |  |   |   |
|--|---|---|
| 1. MOTORCYCLE BRACKET<br>STAFFA MOTOCICLETTA<br>SOPORTE DE MOTOCICLETA<br>MOTORRADHALTERUNG<br>SUPPORT DE MOTO | 5. THREADED THICKNESSES<br>SPESSORE FILETTATO<br>ESPACIADOR ROSCADO<br>GEWINDE ABSTAND<br>ESPACEUR FILETÉ | 9. ALLEN SCREW M5X16<br>VITE A BRUGOLA M5X16<br>TORNILLO ALLEN M5X16<br>INBUSSCHRAUBE M5X16<br>VIS ALLEN M5X16  |
| 2. ALLEN SCREW M6X45<br>VITE A BRUGOLA M6X45<br>TORNILLO ALLEN M6X45<br>INBUSSCHRAUBE M6X45<br>VIS ALLEN M6X45 | 6. SPECIFIC THICKNESS<br>SPESSORE SPECIFICO<br>ESPACIADOR<br>ABSTANDSHALTER<br>ESPACEUR                   | 10. ALLEN SCREW M5X12<br>VITE A BRUGOLA M5X12<br>TORNILLO ALLEN M5X12<br>INBUSSCHRAUBE M5X12<br>VIS ALLEN M5X12 |
| 3. LARGE WASHER Ø6<br>RONDELLA LARGA Ø6<br>ARANDELA ANCHA Ø6<br>BREITE SCHEIBE Ø6<br>LARGE LAVÉUSE Ø6          | 7. RUBBER WASHER<br>RONDELLA DI GOMMA<br>ARANDELA DE GOMMA<br>GUMMISCHEIBE<br>RONDELLE EN CAOUTCHOUC      | 11. WINDSHIELD<br>CUPOLINO<br>PARABRISAS<br>WINDSCHILD<br>SAUTE VENT  |
| 4. SPECIFIC THICKNESS<br>SPESSORE SPECIFICO<br>ESPACIADOR<br>ABSTANDSHALTER<br>ESPACEUR                        | 8. TEFLON WASHER<br>RONDELLA DI TEFLON<br>ARANDELA DE TEFLON<br>TEFLON SCHEIBE<br>RONDELLE EN TEFLON      |   |

